


## FINDING YOUR HUBFACE & SPRING CENTER

MEASURE FROM THE OUTER LEFT EDGE OF ONE HUB TO THE OUTER RIGHT EDGE OF THE OTHER



THIS IS THE FIRST NUMBER IN THE AXLE MEASUREMENT

95/80

MEASURE FROM THE CENTER OF ONE SPRING SEAT TO THE OPPOSITE SPRING SEAT



THIS IS THE SECOND NUMBER IN THE AXLE MEASUREMENT

95/80